XP Power

Digital programming

Interface – operating instructions (Translation from German)

Version 1.0

Contents

OPTIONS	PAGE
IEEE488	2
LAN Ethernet (LANI 21/22)	4
ProfibusDP	9
RS232/RS422	13
RS485	16
USB	19

APPENDIX

Configuration – Baud Rate/Terminator/Commissioning	. 23
Dangers of digital programming misuse	. 24
Testing connection: NI IEEE488 plug-in card	. 25
Testing connection: XP Power Terminal	. 26
Simple communication example	. 27
Instruction set and programming	. 28

OVERVIEW

- The ADDAT 30/31 module is an AD/DA interface for controlling power supplies via fiber optics using serial data transmission. The ADDAT extension board is mounted directly to the device electronics.
- The converter for converting the interface signal to a fibre optics signal mounted at the back panel. To reach highest possible noise immunity, the signal converter can be operated as an external module outside of the power supply. In that case the data transmission outside of the power supply also happens via fibre optics.

This manual was created by: XP Power FuG, Am Eschengrund 11, D-83135 Schechen, Germany



IEEE488



Pin assignment – IEEE488



1	Configuration switches
2	Interface Addressed LED
3	IEEE-488 connector
4	Service Request LED

Interface setup information



For quick setup: Usually, only the GPIB primary address has to be adjusted on the switches 1...5.

The other switches 6...8 remain in OFF position.

Interface Converter LED Indicators

LED ADDR

This LED is on, while the converter is either in listener addressed state or talker addressed state. LED1 SRQ

This LED is on, while the converter asserts the SRQ line. After a serial poll, the LED goes out.



1	Fiber optic transmitter (Tx)
2	Fiber optic receiver (Rx)
3	Mains connection

XP Power

GPIB Primary Address (PA)

The GPIB primary address (PA) enables identification of all units connected to an IEEE-488 bus system.

Therefore, a unique PA must be assigned to each unit on the bus.

The controlling PC usually has PA=0 and the connected units usually have addresses from 4 upwards. In general, the delivery state of FuG power supplies is PA=8.

Adjustment of the PA is done on the back panel of the device on the IEEE-488 interface converter module. It is not necessary to open the power supply.

After changing a configuration switch, the power supply must be switched off for 5 seconds and switched on again to apply the change.



Compatibility Mode Probus IV

If compatibility to a former Probus IV system is necessary, the interface converter can be set to a special compatibility mode (Mode 1).

This mode is not recommended for new designs.

The full efficiency of the new Probus V system can only be achieved in standard mode!





LAN Ethernet (LANI 21/22)



In case of programming a new device control application it is recommended to use TCP/IP for communication. By using TCP/IP, no additional drivers are needed.

Pin assignment – LAN Ethernet (LANI 21/22)





Direct control via TCP/IP

Connection setup and configuration

Depending on your network, some settings have to be made.

First, a connection to the interface converter has to be established. For this, the IP Address has to be determined. The recommended way to detect the device in the Network and to identify its IP Address is to use the Program "Lantronix DeviceInstaller"

CAUTION

Be careful when connecting to a corporate network, because wrong or duplicate IP addresses can cause a lot of trouble and prevent other PCs from network access!

If you are not familiar with network administration and configuration, we strongly recommend to make your first steps in a standalone network without connection to your corporate network (connection via a CrossOver-cable)! Alternatively, please ask your local network administrator for help!

Install DeviceInstaller

Depending on your network, some settings have to be made.

- 1. Download the <u>"Lantronix Device Installer</u>" program from <u>www.lantronix.com</u> and run it.
- 2. After Select your preferred language.



Now it is checked whether "Microsoft .NET Framework
 4.0" or the "DeviceInstaller" is already installed on your PC.

If "Microsoft .NET Framework" is not yet installed, it will be installed first.



4. Accept the license terms of "Microsoft .NET Framework 4.0".





5. The installation of **"Microsoft .NET Framework 4.0"** can take up to 30 minutes.



- 6. Now the installation must be completed via "Finish".
- 7. Then the installation of the "DeviceInstaller" starts.
- 8. Acknowledge the different pages with "Next >".

The installer v	ill guide you throug	gh the steps re	quired to insta	all Lantronix Devi	celnstaller 4.0	3.0.7 (x86)
on your comp	uter.					
WARNING: T	his coros ter prog	am is protecte	d bu conuriabi	law and internal	ional traatiae	
Uppethorized	dunlication or distri	hution of this r	or by copyright	v portion of it. ma	w result in ser	vere civil

9. Choose your folder for the installation.

Lantronix DeviceInstaller 4.3.0.7 (x86)	
Select Installation Folder	
The installer will install Lantronix DeviceInstaller 4.3.0.7 (x86) to the following	folder.
To install in this folder, click "Next". To install to a different folder, enter it belo	w or click "Browse".
Eolder:	
C:\Program Files\Lantronix\DeviceInstaller4.3\	Browse
	Disk Cost
Cancel < Back	Next >

10. Confirm that the program is to be installed.



Now the program "DeviceInstaller" is installed.

TIP

Reboot your System! Otherwise, the DeviceInstaller may seem to run correctly, but will not find any devices!



Detection of the device

NOTE

The following instructions refer to the use of Microsoft Windows 10.

1. After installation, start the "DeviceInstaller" from the Windows start menu.



- 2. If a Windows Firewall warning appears, click on "Allow access".
- 3. All devices found on the network will be displayed. If the desired device is not displayed, you can restart the search with the button **"Search"**.

22 Controllix D'effectivation - Holon				
File Edit View Device Tools Help				
🔎 Search 🤤 Exclude 🔌 Assign IP 🛛 🚳 Upgrade				
E Lantronix Devices - 1 device(s)	Device Details Web Configuration Telnet Config	ration		
ia-∰ Ethernet 3 (192.168.0.124) ia-∰ Unknown	Reload Details			
Unknown(X9) - fimware v6.10.0.3	Property	Value		
	Name	Unknown(X9)		
	DHCP Device Name			
	Group			
	Comments			
	Device Family	Unknown		
	Туре	Unknown(X9)		
	ID	X9		
	Hardware Address	00-80-A3-91-D6-92		
	Firmware Version	6.10		
	Extended Firmware Version	6.10.0.3		
	Online Status	Online		
	IP Address	192.168.2.2		
	IP Address was Obtained	Statically		
	Subnet Mask	255 255 254 0		
	Gateway	0.0.0.0		
	Number of COB partitions sup	oo 6		
	Number of Ports	1		
	TCP Keepalive	45		

 The IP address, in this case 192.168.2.2, is required for connection to the device. Depending on the network configuration, the IP Address may change each time the device is powered down.

After you've obtained the IP-Address via the DeviceInstaller you're able to connect with the device.

Configuration via the web interface

- It is recommended to use a webbrowser for configuration.
 Type the IP address of your device into the address bar and hit enter.
- 2. A login window might be shown, but you only have to click "OK".

By default, no login credentials are required.

Authentifizierung	erforderlich - Mozilla Firefox	×
?	http://192.168.2.2 verlangt einen Benutzernamen und ein Passwo	ort.
Benutzername:		
Passwort:		
	OK Abbrechen	



Customise Settings

A customer specific IP address and subnet mask can be set in the **"Use the following IP configuration"** area. The shown IP addresses / subnet mask are examples. **"Obtain IP address automatically"** is the factory default.

XPo	rt	
<u>ه</u>	Network Setting	gs
Network		
Server	Network Mode: Wired Only •	
Serial Tunnel	IP Configuration	
Hostlist	Obtain IP address automatically	
Channel 1	Auto Configuration Methods	
Serial Settings	BOOTP: Enable Disable	
Email	DHCP' @ Facilia O Dischia	
Trigger 1	Brior . @ Enable O Disable	
Trigger 2	AutoIP: Enable Disable	
Trigger 3	DUCE Liest Nama:	
Configurable Pins	DHCF Host Name.	
Apply Settings	Use the following IP configuration:	
	IP Address: 192.168.178.99	
Apply Defaults	Subnet Mask: 255.255.255.0	
hppij bolaano	Default Gateway: 0.0.0.0	
	DNR Paper	
	Diva Server. 0.0.0.0	
	Ethernet Configuration	
	Auto Negotiate	
	Speed: @ 400 Mitras @ 40 Mitras	
	Capabul. I 100 MBps O 10 MBps	
	Duplex: Full Half	
	ОК	

Local Port

The Local Port "2101" is factory default.

XPo	rf	LANTRONIX
a	Connect	ion Settings
Network Server Serial Tunnel Hostlist Channel 1 Serial Settings Connection	Channel 1 Connect Protocol Protocol: TCP -	
Email Trigger 1	Passive Connection:	Active Connection:
Trigger 2 Trigger 3	Accept Incoming: Yes	Active Connect: None
Configurable Pins	Password Required: O Yes No	Start Character: 0x 0D (in Hex)
Apply Settings	Password:	Modem Mode: None ~
	Modem Escape Sequence Pass Through:	Show IP Address After RING: * Yes O No
Apply Defaults	Endpoint Configuration: Local Port: 2101 Remote Port: 0	Auto increment for active connect Remote Host: 0.0.0.0
	Common Options:	
	Telnet Com Port Cntrl: Disable ~	Connect Response: None ~
	Terminal Name: Hos	Use ○ Yes ● No LED: Blink ┘
	Disconnect Mode	
	On Mdm_Ctrl_In Drop: O Yes No H	lard Disconnect: Yes No
	Check EOT(Ctrl-D): OYes No In	activity Timeout: 0 : 0 (mins : secs)
		ОК

Further Information

The interface converter is based on the embedded device Lantronix-X-Power. Driver updates for new operating systems as well as further information can be obtained from: http://www.lantronix.com/device-networking/embedded-device-servers/xport.html



Profibus DP



Pin assignment of the interface



	 2
	-3

1	ProfibusDP Connector
2	LED BUS ERROR
	ON, if disconnected from
	master
3	LED SERIAL OK
	ON, if the fiber optic
	connection to the ADDAT
	module is operating
	correctly
4,5	Setting of Node Address

1	Fiber optic transmitter (Tx)
2	Fiber optic receiver (Rx)
3	Mains connection



Interface Setup – GSD File

The GSD file of the interface converter is located in the directory **"Digital_Interface\ProfibusDP\GSD"**. Depending on the version of the converter module, either **"PBI10V20.GSD"** has to be used. If the file is incorrect, the power supply unit is not recognized by the master.

Interface Setup - Setting of Node Address

The *node address* identifies the units (=nodes) connected to the Profibus. A unique address must be assigned to every node on the bus. The address is set with switches on the rear side of the interface converter. The housing of the power supply does not need to be opened.

After any change in the configuration, the power supply (interface converter) must be switched off for at least 5 seconds. Slave addresses in the range 1...126 are possible.

Indicators

Green LED -> SERIAL OK

This LED is on, if the serial fiber optic connection between ADDAT base module and interface converter is working correctly.

At the same time, the LED **BUSY** on the front panel of the power supply is continuously on, indicating a continuous data transfer between the interface converter and the ADDAT base module.

Red LED -> BUS ERROR

This LED is on, if there is no connection to the ProfibusDP Master.

Mode of Operation

The ProfibusDP interface converter provides a 16 Byte input data block and a 16 Byte output data block.

Incoming data from Profibus is stored in the input data block.

This block is transferred cyclically as a 32-character hexadecimal string to the ADDAT base module. (Register ">H0" of ADDAT 30/31)

The ADDAT base module responds with a 32-character hexadecimal string.

This string contains 16 Bytes of monitor and status signals.

The Profibus interface converter stores these 16 Bytes in the output data block, which can be read by the Profibus master.

The cycle time is approximately 35ms.

Please refer also to the description of Register ">H0" in document Digital Interfaces Command Reference ProbusV.

Date Formats

Data format input data block ">H0"		
Byte		
0	LSB	Set value "0" (Voltage set value), unsigned integer,
1	MSB	"065535" represents 0V to nominal voltage in ">CS0T", ">S0" is set
2	LSB	Set value "1" (Current set value), unsigned integer "065535" represents 0A to nominal current in ">CS1T", ">S1" is set
3	MSB	
	Bit 0	Sign for "0" ("0" = pos., "1" = neg.)
4	Bit 1	Sign for "1" ("0" = pos., "1" = neg.)
	Bit 2	Not used



Power

Data format output data block ">H1"		
Byte		
0	LSB	Monitor "0" (voltage monitor), unsigned integer,
1	MSB	(Value from register ">M0"), "065535" represents 0V to nominal voltage in ">CM0T"
2	LSB	Monitor "1" (current monitor), unsigned integer,
3	MSB	(Value from register ">M1"), "065535" represents 0A to nominal current in ">CM1T"
4	Bit 0	Sign of Monitor "0" ("0" = pos., "1" = neg.)
	Bit 1	Sign of Monitor "1" ("0" = pos., "1" = neg.)
	Bit 2	Not used
	Bit 3	Not used
	Bit 4	Not used



	Bit 5	Not used	
	Bit 6	Not used	
	Bit 7	Not used	
	Bit 0	Input signal "SEL-D" ("1" = power supply is digitally controlled)	
	Bit 1	Input signal "SEL-A" ("1" = power supply is analogously controlled)	
	Bit 2	"CAL-Mode" ("1" = power supply is in calibration mode)	
5	Bit 3	Input signal "X-STAT" (polarity of HVPS with polarity reversal)	
5	Bit 4	Input signal "3-REG" (for special applications)	
	Bit 5	Input signal "ON-STAT" ("1" = power supply ON)	
	Bit 6	Input signal "V-REG" ("1" = power supply is in constant-voltage regulation)	
	Bit 7	Input signal "I-REG" ("1" = power supply is in constant-current regulation)	
6		Not used	
7		Not used Not used Not used	
8			
9			
10	LSB		
11		Sorial number long integer	
12		Senachumber, tong integer	
13	MSB		
14		Error code of the most recent command	
15		SYNC Byte, value is copied from input data block	

More Information

The interface converter Profibus DP is based on the standard converter "UNIGATE-IC" from Deutschmann Automationstechnik (product page).

All common Profibus baud rates up to 12 MBit/s are supported.

The conversion settings are script-controlled with a cycle time of approx. 35ms.



RS232/422



Interface setup information

Each Device which is equipped with a RS232, or a RS422 internal or external converter, can be remotely controlled via a PC over the COM port. From the view of the application programmer, there is no difference between these variations.

RS232, external interface converter

The power supply is connected to the pc via a Plastic Optic Fiber link (POF). This ensures highest possible noise immunity.

The maximum link distance is 20m.

On the PC side, the interface converter is connected directly to a standard COM port. The interface signal Tx is used to power the converter, therefore no external supply is needed.

Fiber optic connections:

The data output of the converter ("T", Transmit) needs to be connected to the data input ("Rx", Receive) of the power supply.

The data input of the converter ("R", Receive) needs to be connected to the data output ("T", Transmit) of the power supply.







Pin assignment – RS232, intern





1	Sub-D connector

1	Fiber optic transmitter (Tx)
2	Fiber optic receiver (Rx)
3	Mains connection

Connector pin assignment:	
2	Tx Data Output
3	Rx Data Output
5	GND
1,9	Not connected
4-6	Internally shorted
7 - 8	Internally shorted

To establish a connection to a standard PC it is sufficient to connect pins 2, 3 and 5 with the same pin numbers at the PC com port.

Standard RS-232 cables with 1:1 pin connection are recommended.



There are NULL-modem cables existing with Pins 2 and 3 crossed. Such cables do not work.



Pin assignment – RS422





Connector Pin assignment:	
1	Tx- Transmit data
2	Tx+ Transmit data
3	Rx+ Receive data
4	Rx- Receive data
5	GND
7 - 8	Internally shorted
6, 9	Not connected

CAUTION

The pin assignment follows a quasi-standard. Therefore, it cannot be guaranteed, that the pin assignment is compatible to your PC RS-422 output. In case of doubt, the pin assignment of the PC and interface converter has to be verified.



RS485



RS485 Background Information

The **"RS485 Bus"** is mostly associated with a simple 2-wire bus system that is used to connect multiple addressed slaves with a master device (i.e. PC).

It only defines the signal levels on the physical layer of communication.

RS485 does not define any data format, nor any protocol or even a connector pin assignment!

Therefore, every manufacturer of RS485 equipment is absolutely free in defining how the units on the RS485 bus communicate with each other.

This results in different units from different manufacturers usually not working together correctly. To enable different units from different manufacturers working together, complex standards like **ProfibusDP** were introduced. These standards are based on RS485 on the physical layer, but also define the communication on higher levels.

Interface Converter RS232/USB to RS485

A PC with a common RS232/USB interface can be adapted to RS485 by interface converters available on the market.

Usually, these converters work well in full duplex mode (2 pairs of wires).

In half duplex mode (1 pair of wires), the transmitter of each station must be disabled immediately after the last byte was sent to clear the bus for the next data expected.

In most available RS232 - RS485 interface converters the transmitter is controlled via the RTS signal. This special use of RTS is not supported by standard software drivers and requires special software.



Pin assignment – RS485





1	Sub-D connector

1, 2	Fiber optic transmitter (Tx, equivalent)
3, 4	Fiber optic receiver (Rx, equivalent)
5	Mains connection

Connector Pin assignment:	
1	Tx- Transmit data
2	Tx+ Transmit data
3	Rx+ Receive data
4	Rx- Receive data
5	GND
7 - 8	120 Ohm resistor
6,9	Not connected

RS485 does not define any pin assignment. The assignment of the pins corresponds to usual systems. Most likely, the pin assignment on PC side or other equipment will be different!

Configuration - Address

Address 0 is the factory default.

If more than one device is linked together via RS485, the favored addresses can be set as factory default. In that case, please contact XP Power.

In a normal use case, changing the addresses of the devices is therefore not necessary.

The calibration mode needs to be enabled in order to change the address of a device. Activation of the calibration mode is done at your own risk! In order to do so, the device needs to be opened which should be done by trained personnel only! The current safety regulations are to be satisfied!



Network Structure and Termination

The bus should have a linear structure with 120 Ohm termination resistors on both ends. In half duplex mode, the 120 Ohm resistor between Pins 7 and 8 can be used for this purpose.

Star topology or long branch wires should be avoided to prevent signal degradation due to reflections.

The master device can be located anywhere within the bus.

Fullduplex Mode (separated Rx and Tx)

The bus consists of 2 wire pairs (4 signal wires and GND)

Timing: The Answer time of the ADDAT module is significantly below 1ms (typically a few 100us). The master must wait at least 2ms after receiving the last byte of an answer string before starting to send the next command string.



Otherwise, data collision on the bus may occur.

Half duplex Operation (Rx and Tx combined on one Wire Pair)

The bus consists of 1 wire pair (2 signal wires and GND)

Timing 1: The Answer time of the ADDAT module is significantly below 1ms (typically a few 100us). The master must be able to switch off its transmitter within 100us after the last byte transmitted.

Timing 2: The slave's transmitter (Probus V RS-485 interface) remains active for a maximum of 2ms after the last byte transmitted and is set to high impedance after this. The master must wait at least 2ms after receiving the last byte of an answer string before starting to send the next command string.

Violating these timing constrains leads to data collision.





USB



Pin assignment - USB





1	LED indicator Tx
2	USB port
3	LED indicator Rx

1	Fiber optic receiver (Rx)
2	Fiber optic transmitter (Tx)



Installation

The USB interface works together with the driver software as a virtual COM port.

Therefore, it's easy to program the power supply without special USB knowledge. You can even use existing software that worked up to now with a real COM port.

Please use the driver installation file from the <u>XP Power Terminal</u> package.

Automatic Driver Installation

- 1. Connect the power supply to the PC via the USB cable.
- 2. If there is an available internet connection, Windows 10 will silently connect to the Windows Update website and install any suitable driver it finds for the device.

Installation is complete.

Installing	USB	<->	Serial	Converter
------------	-----	-----	--------	-----------

Ĵ	Please wait while Setup installs necessary files on your system. This may take several minutes.	
	Close	e

Installation via executable setup file

1. The executable CDM21228_Setup.exe is located in the XP Power Terminal download packet.

2. Right-click the executable and choose "Alle extrahieren..."



3. Run the executable as administrator and follow the instructions.

$\leftarrow \ \ \rightarrow \ \ \land \ \ \land$	Market State And Antipartic Content and An		
Name	^	Änderungsdatum	Тур
CDM21228_	Setup.exe	Open	^end
	•	Run as administrator	
		Troubleshoot compatibility	

XP Power

. 🧐 FTDI CD	A Drivers ×		
	FTDI CDM Drivers		
/	Click 'Extract' to unpack version 2.12.28.2 of FTDI's Windows driver package and launch the installer.		
4	www.ftdichip.com		
	< Back Extract Cancel		
. Device Drive	r Installation Wizard		
	Welcome to the Device Driver Installation Wizard!		
	Computers devices need in order to work.		
	To continue, click Next.		
	< Back Next > Cancel		
Device Drive	r Installation Wizard		
License	Agreement		
%	To continue, accept the following license agreement. To read the entire agreement, use the scroll bar or press the Page Down key.		
	IMPORTANT NOTICE: PLEASE READ CAREFULLY BEFORE INSTALLING THE RELEVANT SOFTWARE: This licence agreement (Licence) is a legal agreement between you (Licensee or you) and Future Technology Devices International Limited of 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, Scotland (UK Company Number SC136640) (Licensor or we) for use of driver software provided by the Licensor(Software).		
	I accept this agreement Save As Print		
	< Back Next > Cancel		



Once the installation is complete, click "finish".





Appendix

Configuration

Baud Rate

The default Baud rate for devices with a:

- USB interface is set to 115200 Baud. The maximum baud rate for USB is 115200 Baud.
- LANI21/22 interface is set to 230400 Baud. The maximum baud rate for LANI21/22 is 230k Baud.
- RS485 interface is set to 9600 Baud. The maximum baud rate for RS485 is 115k Baud.
- RS232/RS422 interface is set to 9600 Baud. The maximum baud rate for RS485 is 115k Baud.

Terminator

The termination character "LF" is the factory default.

Commissioning



- 1. Before beginning the commissioning of the interface, the DC power supply must be switched off.
- 2. The interface of the control computer is to be connected to the interface of the DC power supply as specified.
- 3. Now turn on the POWER switch.
- 4. Press the REMOTE switch (1) on the front panel so that the LOCAL LED (2) turns off. If an additional analog interface is present, set the switch (6) to DIGITAL. The DIGITAL LED (5) light up.
- 5. Start your operating software and establish the connection to the interface in the device.
 - The device is now controlled via the operating software. The BUSY LED (4) lights up shortly during data traffic for monitoring purposes. Further information about the commands and functions can be found in the document **Digital Interface Command Reference Probus V**







To safely switch off the power supply, proceed as follows:



 After the output is less than <50V, switch the unit completely off using the POWER (1) switch. Pay attention to the residual energy in your application!

The DC power supply is switched off.

Dangers of digital programming misuse





Danger of electrical shock at the power outputs!

If the digital interface cable is pulled during the device operating in DIGITAL mode, the outputs of the device will maintain the last set value!

When switching from DIGITAL mode to LOCAL or ANALOG mode, the outputs of the device will maintain the last set value set via the digital interface.

If the DC supply is turned off via the POWER switch or by an outage of the voltage supply, the set values will be set to "0" when the device is restarted.



Testing the connection: NI IEEE-488

If you use a National Instruments IEEE-488 plug in card in your PC, the connection can be tested very easily. The card is delivered together with a program: the **"National Instruments Measurement And Automation Explorer"**. Short form: **"NI MAX"**. It is used for the following example.



Other manufacturers of IEEE-488 boards should have similar programs. Please refer to the manufacturer of your card.

Example for NI MAX, Version 20.0

- 1. Connect the FuG power supply to the PC via IEEE-488.
- 2. Start NI MAX and click on "Geräte und Schnittstellen" and "GPIB0".



3. Now click on "**Scan for Instruments**". The power supply will respond with "FuG", Type and serial number.





4. Click on "Kommunikation mit Gerät":

Now you can type a command into the "Send" field:

After starting the communicator, the string **"*IDN?"** is already placed in the input field. This is the standard query for the identification string of the device.

NI-488.2 Communicator			×
GPIB0 Primary Addres	s 8		
Send *IDN?	-Globals ibsta: 0	x100	Status ERR TIMO
<u>Q</u> uery <u>W</u> rite <u>R</u> ead	iberr: N	one	END
Configured	ibcntl: 4	ŧ –	SRQI
String Received:			RQS CMPL
		^	REM CIC ATN
		~	TACS LACS DTAS
<u>C</u> onfigure EOS <u>S</u> how Sample	E <u>x</u> it		DCAS

If you click on **"QUERY"** the "Send" field is transmitted to the power supply and the answer string is displayed in the "String Received" field.

If you click on **"WRITE"**, the "Send" field is sent to the power supply, but the answer string is not collected from the power supply.

A click on "READ" collects and displays the answer string.

("QUERY" is just a combination of "WRITE" and "READ".) 5. Click on **"QUERY"**:

🔚 NI-488.2 Communicator		×
GPIB0 Primary Addres	s 8	
Send *IDN?	Globals ibsta: 0x2100	Status ERR
Query <u>W</u> rite <u>R</u> ead	iberr: None	FND
Configured	ibcntl: 30	SRQI
String Received:		RQS CMPL
FuG HCP200-6500 23594-01-01	^	LOK REM
		CIC ATN
	~	TACS LACS
Configure EOS Show Sample	E <u>x</u> it	DTAS DCAS



The power supply outputs type and serial number.

Testing the connection: XP Power Terminal

The <u>XP Power Terminal</u> program can be used to test the connection to the power supply unit. This can be downloaded from the Resources tab on each XP Power Fug product page.



Simple communication examples

IEEE488

To connect the device, almost any terminal program can be used.

Command:

>S0 x	Sends set value for voltage, x = value
>S1 y	Sends set value for current, y = value
A DANGER	By sending the command ">BON 1" the output is activated immediately.
>BON 1	Sends command HV-ON
>BON 0	Sends command HV-OFF
>M0?	Query for current voltage monitor
>M1?	Query for current current monitor

ProfibusDP

Voltage set value

Input data block Bytes 0 (=LSB) and Byte 1 (=MSB)

0...65535 results in 0...nominal voltage.

In bipolar power supplies the set value can be inverted by setting of Byte4/Bit0.

Current set value

Input data block Bytes 2 (=LSB) and Byte 3 (=MSB)

0...65535 results in 0...nominal current.

In bipolar power supplies the set value can be inverted by setting of Byte4/Bit1.

Release output voltage

By sending the changed input block (register ">BON") the output is activated immediately!

Input data block Byte 7, Bit 0

The output of the power supply is electronically released and switched off.

Read back of output voltage

Output data block Bytes 0 (=LSB) and Byte 1 (=MSB)

0...65535 results in 0...nominal voltage.

The sign of the value is in Byte4/Bit0 (1 = negative)

Read back of output current

Output data block Bytes 2 (=LSB) and Byte 3 (=MSB)

0...65535 results in 0...nominal current.

The sign of the value is in Byte4/Bit1 (1 = negative)



Instruction set and programming

For a complete overview of the registers with further commands and functions refer to the document **Digital Interfaces Command Reference Probus V**.

The power supply unit is controlled via simple ASCII commands. Before transmitting a new command, the response corresponding to the previous command should be waited for and evaluated if needed.

- Each command string must be terminated by at least one of the following termination characters or any combination of them: "CR", "LF" or "0x00".
- Each command string sent to the power supply unit will be answered by a corresponding response string.
- "empty" command strings, i.e. strings consisting only of termination characters, are rejected and do not return an answer string.
- All read data and handshake strings from the power supply unit are terminated with the set terminator (see register ">KT" or ">CKT" and "Y" command)
- Receive timeout:

•

If no new character has been received for longer than 5000ms all previously received characters will be discarded. Due to the relatively long timeout, it is possible to transmit commands manually using the terminal program.

- **Command length:** The maximum command string length is limited to 50 characters.
- **Receive buffer:** The ADDAT has a 255 characters long FIFO Receive Buffer.